



ASSEMBLY INSTRUCTIONS

SAFESTEP MIMER – FRP STAIR NOSING

Safestep MIMER can be installed either by glue or screws, depending on the surface. Not sure which method to choose? Contact us and we will guide you through it all.

Tools.

The following tools are not required, but may facilitate a hassle-free application.

- Microfiber towel
- Suitable detergent
- Angle grinder or tiger saw with diamond blade
- Measuring instrument
- Mounting glue – we recommend TEC7
- Power drill / driver
- Stainless screws
- Weight of your choice
- Personal protective equipment

Preparing the product.

Using an angle grinder or tiger saw, cut the stair nosing profiles into the right dimensions. Be careful and wear personal protective equipment!

Surface preparations.

1. Ensure the stairs are stable and in good condition so that the assembly safely takes place. Any damages should be repaired prior to installation.
2. Thoroughly clean the surface and the back of the profiles. Both surfaces and profiles should be clean, dry, and free from grease and contamination.

Assembly with glue.

1. Run a bead of glue in an S-like pattern along the entire profile.
2. Place the product onto the front edge of the stair tread and fix it into place, preferably using a weight of any kind.
3. The glue might need some time to harden. Always read and follow the package instructions. When the glue is fully hardened the stairs are ready for use.

Assembly with screws.

1. Using a power drill, predrill screw holes to prevent the product from cracking. Measure and mark the holes with a pen before drilling.
2. The holes should be drilled 50 mm from the edges, with a distance of 250 mm in between.
3. Attach the profiles with stainless screws. Tighten the screws properly.
4. The stair nosing profiles are ready for use right away.

Maintenance.

- Safestep MIMER withstands extreme loads and harsh weather conditions without flaking or corroding. When installed correctly, the profiles have an extremely long durability.
- Use a brush to keep the profiles clean of dirt. If needed, the profiles can be cleaned using a high-pressure washer and detergent.
- Check the assembly regularly to ensure that neither screws or adhesive is loosening.