



## APPLICATION

### SAFESTEP SAGA

#### Tools.

The following tools are not required, but may facilitate a hassle-free application.

- Microfiber towel
- Suitable detergent
- Rubber roller

#### Notice:

The product is unsuitable for application on untreated metal, raw wood, stone, brick, and uneven/structured surfaces. Ensure that the surface is clean and completely dry before applying the product.

#### Surface preparations.

1. The surface should be clean, dry, and free from grease and contamination. Clean the surface thoroughly and make sure it is completely dry.

#### Application.

1. Remove the plastic film approx. 50 mm and place the product on the surface.
2. Continue to gradually peel off the plastic film and press the tape firmly in place.
3. Use a rubber roller and firmly press out any bubbles, starting from the center and out towards the edges.
4. The product can be loaded immediately after application.