

APPLICATION

SAFESTEP ERIKSBERG – CONTRAST MARKINGS PREMIUM

Tools.

The following tools are not required but may facilitate a hassle-free application.

- Microfiber towel
- Suitable detergent
- Application template
- Measuring instrument
- Rubber roller

Surface preparations.

1. The surface should be clean, dry, and free from grease and contamination. Clean the surface thoroughly and make sure it is completely dry.

Application.

1. Measure the correct distance between the dots (30 mm), preferably with a ready-made template for correct placement. When installed on stairs, the dots should be placed 20 mm from the front edge of the step.
2. One by one, peel off the releasing paper and place it onto the surface.
3. Use a rubber roller and firmly press the markings into place.
4. The markings can be loaded immediately after application. However, it takes about 72 hours before the adhesive has fully hardened. Therefore, the temperature should not drop significantly during the curing time.