



APPLICATION

SAFESTEP MOOSE GRIP – ANTI-SLIP TAPE

Tools.

The following tools are not required, but may facilitate a hassle-free application.

- Microfiber towel
- Suitable detergent
- Measuring instrument
- Rubber roller
- Scissor and/or knife

Surface preparations.

1. The surface should be clean, dry, and free from grease and contamination. Clean the surface thoroughly and make sure it is completely dry.

Application.

1. Measure and cut the tape to the right dimensions.
2. Remove the plastic film approx. 50 mm and place the tape on the surface.
3. Continue to gradually peel off the plastic film and press the tape firmly in place.
4. Use a rubber roller and firmly press out any bubbles, starting from the center and out towards the edges.
5. The tape can be loaded immediately after application. However, it takes about 72 hours before the adhesive has fully hardened. Therefore, the temperature should not drop significantly during the curing time.